

BLUED &
STAINLESS
STEEL



CALIBER
.22 Long Rifle

RUGER® MARK III™
AUTOLOADING PISTOLS
STANDARD, TARGET, GOVERNMENT TARGET,
COMPETITION AND 22/45 MODELS



All parts orders for the **MARK III™** pistols should be sent to: Sturm, Ruger & Co., Inc., Parts Department, 200 Ruger Road, Prescott, AZ 86301, 928-778-6555. Payment in the form of a check, money order, Visa or MasterCard must accompany your order. Credit card orders must include the account number, expiration date, and whether it is a Visa or MasterCard account. We cannot comply with open account or C.O.D. requests. Minimum parts order is \$1.00 plus a \$3.50 shipping and handling charge. Order parts by part name and part number and include the entire serial number of the firearm for which the parts are being ordered. The price shown for parts does not include the minimum net labor charge of \$20.00 plus \$20.00 shipping and handling if parts are factory fitted. All factory fitted parts are fitted on an exchange basis only. We will not return the replaced parts. The charge for metal refinishing is \$50.00 plus a \$20.00 shipping and handling charge. Custom gunsmithing service or nonstandard alterations are **NOT AVAILABLE**.

Because it is a serial-numbered component, the Automatic Pistol Barrel-Receiver Assembly is defined as a “firearm” by Federal Law and is not sold as a separate component. The Barrel-Receiver of the Ruger Mark III autoloading Pistol is an integrated assembly, therefore, the barrel alone is not available as a separate component part.

Some parts are available in blued steel only or stainless steel only and are used on all models. A few components (for example, grip panels) are the same for blued and stainless models.

Design, specifications and prices are subject to change without notice. The Sturm, Ruger & Company “LOGO” and “RUGER” are registered U.S. trademarks.

STURM, RUGER & Company, Inc.
Southport, Connecticut 06890 U.S.A.

MARK III™

COMPONENT PARTS AND SUGGESTED RETAIL PRICES

ORDER THESE PARTS FROM PRESCOTT PLANT

Key No.	Part Name	Part No.	Model
* 1	Barrel/Receiver Assembly	AB5300-512 KAB5300-512 APB5300-512 KAPB5300-512	MKIII Target - blued model MKIII Target - stainless model 22/45 MKIII - blued model 22/45 MKIII - stainless model
2	Front Sight	A03612	MKIII & 22/45 MKIII models
3	Front Sight Screw	XR07600	MKIII & 22/45 MKIII models
4	Barrel/Receiver Filler Screws, 3 Req'd	B-83	MKIII & 22/45 MKIII models (except Standard Models)
5	Loaded Chamber Indicator	A11001 KA11001	MKIII & 22/45 MKIII - blued models MKIII & 22/45 MKIII - stainless models
6	Loaded Chamber Indicator Spring	KAP04600	MKIII & 22/45 MKIII models
7	Loaded Chamber Indicator Pin	A02611	MKIII & 22/45 MKIII models
	Rear Sight Assembly, Complete - Includes Key Nos. 8 - 15 (Not Available on Standard Models)	A15901-200	
8	Rear Sight Bottom	A05900	MKIII & 22/45 MKIII models
9	Rear Sight Pivot Pin	A05601	MKIII & 22/45 MKIII models
10	Rear Sight Elevation Springs, 2 Req'd	MR05906	MKIII & 22/45 MKIII models
11	Rear Sight Base	A06102	MKIII & 22/45 MKIII models
12	Rear Sight Elevation Screw	MR05902	MKIII & 22/45 MKIII models
13	Rear Sight Blade	MR05901	MKIII & 22/45 MKIII models
14	Rear Sight Windage Spring	MR05907	MKIII & 22/45 MKIII models
15	Rear Sight Windage Adjustment Screw	E05903	MKIII & 22/45 MKIII models
	Bolt Assembly, Complete - Includes Key Nos. 16 - 24	A02111-100 KA02111-100	MKIII & 22/45 MKIII - blued models MKIII & 22/45 MKIII - stainless models
16	Bolt, Only	A02111 KA02111	MKIII & 22/45 MKIII - blued models MKIII & 22/45 MKIII - stainless models
17	Firing Pin Stop Pin	A03500	MKIII & 22/45 MKIII - blued models
18	Rebound Spring	KA03500 A20000 KA20000	MKIII & 22/45 MKIII - stainless models MKIII & 22/45 MKIII - blued models MKIII & 22/45 MKIII - stainless models
19	Rebound Spring Support	A03900 KA03900	MKIII & 22/45 MKIII - blued models MKIII & 22/45 MKIII - stainless models
20	Firing Pin	A01300	MKIII & 22/45 MKIII models
21	Recoil Spring Assembly	KA-57	MKIII & 22/45 MKIII models
22	Extractor Spring	KA20300	MKIII & 22/45 MKIII models
23	Extractor Plunger	KA02510	MKIII & 22/45 MKIII models
24	Extractor	KA02200	MKIII & 22/45 MKIII models
* 25	Grip Frame with Trigger Guard	A54002 KA54002	MKIII - blued models MKIII - stainless models
	Grip Frame, One Piece, Plastic	AP10200	22/45 MKIII models
* 26	Trigger	A01202 A01203-100 A01252 A01202 A20400	MKIII & 22/45 MKIII (except Target models) MKIII Target 22/45 MKIII Target 22/45 MKIII MKIII & 22/45 MKIII - blued models
27	Trigger Spring	KA20400	MKIII & 22/45 MKIII - stainless models
28	Trigger Spring Plunger	A02508 KA02508	MKIII & 22/45 MKIII - blued models MKIII & 22/45 MKIII - stainless models
29	Trigger Pivot Retainer	KA04200	MKIII Models
30	Bolt Stop Assembly (See Notes A & B on Pages 36 & 37)	AP04200 AN-37 KAN-37 AP-37	22/45 MKIII models MKIII - blued model MKIII - stainless models 22/45 MKIII models
31	Bolt Stop Plunger (See Notes A & B on Pages 36 & 37)	A04300 KA04300 A02511	MKIII - blued models MKIII - stainless models 22/45 MKIII models
32	Bolt Stop Plunger Spg. (See Notes A & B on Pgs. 36 & 37)	KA04600 AP04600	MKIII models 22/45 MKIII models
33	Trigger Pivot Pin	A03400 KA04300 AP03401	MKIII - blued models MKIII - stainless models 22/45 MKIII models

* Parts designated by an asterisk must be factory fitted. These parts are fitted on an exchange basis only. We will not return the replaced parts. We will not return any part that is broken, malfunctioning, badly worn or has been modified. See "Warning — Parts Purchasers", page 4.

MARK IIITM

COMPONENT PARTS AND SUGGESTED RETAIL PRICES

ORDER THESE PARTS FROM PRESCOTT PLANT

Key No.	Part Name	Part No.	Model
* 34	Safety Assembly, Complete	AN-53-100 KA-53-100 AP-53-100	MKIII - blued models MKIII - stainless models 22/45 MKIII models
* 35	Hammer Assembly, Complete	A01803-100 KA01803-100 A01802-100	MKIII & 22/45 MKIII - blued Target models MKIII & 22/45 MKIII - stainless Target models MKIII & 22/45 MKIII Standard models
36	Magazine Disconnecter Spring	A20250	MKIII & 22/45 MKIII models
37	Magazine Disconnecter	KA01110	MKIII & 22/45 MKIII models
* 38	Disconnecter Assembly	KA011	MKIII & 22/45 MKIII models
39	Hammer Bushing	KA02513	MKIII & 22/45 MKIII models
40	Sear Spring	A03100 AP03100	MKIII models 22/45 MKIII models
* 41	Sear	A01901	
42	Bolt Stop Thumb Piece	A04700 KA04700	MKIII - blued models MKIII - stainless models
43	Hammer Pin (See WARNING, below)	A02605 KA02605 AP02613	MKIII - blued models MKIII - stainless models 22/45 MKIII models
44	Magazine Latch	A00503 KA00503 AP00504	MKIII - blued models MKIII - stainless models 22/45 MKIII models
45	Magazine Latch Spring	KAP03000	MKIII & 22/45 MKIII models
46	Magazine Latch Spring Plunger	KE-61	
47	Magazine Latch Screw	A08003	MKIII models
48	Sear Pin	A02601 KA02601 AP02612	MKIII - blued models MKIII - stainless models 22/45 MKIII models
49	Sear Spring Pin	A02603	MKIII models
50	Magazine Latch Pin, 2 Req'd	A02601	MKIII models
51	Mainspring Housing Assembly	A00910-100 AP00903-100	MKIII models 22/45 MKIII models
52	Lock Pin	KA02614	MKIII & 22/45 MKIII models
53	Spring Back-up Pin	KA02616	MKIII & 22/45 MKIII models
54	Detent Plunger Lock	KV04612	MKIII & 22/45 MKIII models
55	Lock Plunger Detent Spring	KV06476	MKIII & 22/45 MKIII models
56	Hammer Spring Plunger	KA02509	MKIII & 22/45 MKIII models
57	Hammer Spring	A20100	MKIII & 22/45 MKIII models
58	Housing Latch Detent Ball	A04100	MKIII & 22/45 MKIII models
59	Housing Latch	A00700 KA00700 AP00700	MKIII - blued models MKIII - stainless models 22/45 MKIII models
60	Housing Latch Pin	A02602	MKIII & 22/45 models
61	Grip Frame Filler	A00401	MKIII models
62	Grip Panel, Left	A00811	MKIII models
63	Grip Panel, Right (with medallion)	A00810-100	MKIII models
64	Grip Panel Screw, 2 Req'd	A02503	MKIII models
65	Magazine, Complete	M10MKIII AP10MKIII	MKIII models 22/45 MKIII
66	Internal Lock Key	KV15009	MKIII & 22/45 MKIII models
Mark III Competition Model Component Parts Includes Key Nos. 67 - 71 (See Note C, page 38.)			
67	Scope Mount Base (3.421"), with Screws	A07000	MKIII & 22/45 MKIII models
	Scope Mount Base (4.125"), Extended, with Screws	A07001	MKIII & 22/45 MKIII models
68	Scope Base Screws, 3 Req'd	B-89	MKIII & 22/45 MKIII models
69	Scope Rings, Low, Blued	S100RL	MKIII & 22/45 MKIII models
	Scope Rings, Low, Stainless	KS100RL	MKIII & 22/45 MKIII models

* Parts designated by an asterisk must be factory fitted. These parts are fitted on an exchange basis only. We will not return the replaced parts. We will not return any part that is broken, malfunctioning, badly worn or has been modified. See "Warning — Parts Purchasers", page 4.

WARNING regarding non-Ruger Grip Panels. Note: The Hammer Pin (A02605) is prevented from drifting out of the left side of the Grip Frame by contact with the inner surface of the left Grip Panel. Therefore, be certain that the clearance cut in the left Grip Panel is the correct depth to maintain the Hammer Pivot fully seated in the Grip Frame.

MARK IIITM

COMPONENT PARTS AND SUGGESTED RETAIL PRICES

ORDER THESE PARTS FROM PRESCOTT PLANT

Key No.	Part Name	Part No.	Model
70	Front Sight	A03604	MKIII - Competition model
71	Front Sight Screw	XR07600	MKIII & 22/45 MKIII models
	Also Available, but Not Illustrated		
	Weaver-Style Scope Mount Base, with Screws, Matte Silver Color	A07050G	MKIII & 22/45 MKIII models
	Weaver-Style Scope Mount Base, with Screws, Matte Black Color	A07050B	MKIII & 22/45 MKIII models
	Case Only	PGC-RF	MKIII & 22/45 MKIII models



WARNING—PARTS PURCHASERS




It is the purchaser's responsibility to be absolutely certain that any parts ordered from the factory are correctly fitted and installed. Firearms are complicated mechanisms and IMPROPER FITTING OF PARTS MAY RESULT IN A DANGEROUS MALFUNCTIONING, DAMAGE TO THE FIREARM AND SERIOUS INJURY TO THE SHOOTER AND OTHER PERSONS. The purchaser and installer of parts must accept full responsibility for the correct adjustment and functioning of the firearm after such installation.

PARTS MUST FIT CORRECTLY

RUGER® MARK III™ EXPLODED VIEW

Note A: The Bolt Stop components in this group are for holding open the bolt and are not functionally related to the Bolt Stop Pin and Bolt Stop Pin Pivot. These two later components are attached to the Mainspring Housing (Key No. 51; Part No. A00910-100). See parts drawing below for relationship of parts.



RUGER® 22/45 MARK III™

EXPLODED VIEW

Note B: The Bolt Stop components in this group are for holding open the bolt and are not functionally related to the Bolt Stop Pin and Bolt Stop Pin Pivot. These two later components are attached to the Mainspring Housing (Key No. 51; Part No. AP00903-100). See parts drawing below for relationship of parts.

